

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

Last updated, May 11, 2009

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
-------	------	---------	---------------------	---------------------	---------------	--------------	---------------	---

HARLEY DAVIDSON

Softail® Bad Boy - FXSTSB	1984 to 2005	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Fat Boy® - FLSTF/FLSTFI/FLSTFSE	1984 to 2006	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Softail® Fat Boy® - FLSTF/FLSTFI * With 200mm wide rear tire	2007 to present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Softail® Cross Bones® - FLSTSB	2008 to present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Heritage Softail® - FLST/FLSTI	1984 to 2005	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Heritage Softail® - FLST/FLSTI	2006 to Present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		* With 200mm wide rear tire GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Heritage Softail® Classic - FLSTC/FLSTCI	1984 to Present	GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
* With Heritage Bags		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
* Without Heritage Bags		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
Heritage Softail® Special - FLSTN	1993-1996	GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Heritage Springer® - FLSTS/FLSTSI	1984 to Present	GB-HD-UKH-105	GB1-ADJ-105 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	No turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-105	GB1-ADJ-105 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKHDBK-105	GB1-ADJ-105 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Heritage Softail® - FLST/FLSTI * With 200mm wide rear tire	2006 to Present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Softail® Night Train™ - FXSTB/FXSTBI	1984 to 2005	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Night Train™ - FXSTB/FXSTBI * With 200mm wide rear tire	2006 to Present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Custom - FXSTC	1984 to 2006	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Softail® Custom - FXSTC	2007 to Present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
* With 200mm wide rear tire		GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Softail® Deluxe - FLSTN/FLSTNI	1984 to Present	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	No turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Softail® Deuce™ - FXSTD/FXSTDI	1984 to Present	GB-HD-DC-105	GB1-ADJ-105 + GB1-KHK-HD-DC	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-DC-106	GB1-ADJ-106 + GB1-KHK-HD-DC	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with large saddlebags 20" or more in width	N/A
Screamin' Eagle® Deuce™ - FXSTDSE/FXSTDSE2	1984 to Present	GB-HD-DC-105	GB1-ADJ-105 + GB1-KHK-HD-DC	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-DC-106	GB1-ADJ-106 + GB1-KHK-HD-DC	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with large saddlebags 20" or more in width	N/A
Softail® Deuce™ - FXSTD/FXSTDI	1984 to Present	GB-HD-DCH-105	GB1-ADJ-105 + GB1-KHK-HD-DCH	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags 22" or less in width	N/A
		GB-HD-DCH-106	GB1-ADJ-106 + GB1-KHK-HD-DCH	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags 20" or more in width	N/A
Screamin' Eagle® Deuce™ - FXSTDSE/FXSTDSE2	1984 to Present	GB-HD-DCH-105	GB1-ADJ-105 + GB1-KHK-HD-DCH	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags 22" or less in width	N/A
		GB-HD-DCH-106	GB1-ADJ-106 + GB1-KHK-HD-DCH	Under fender rail setup using chrome bracket	No turn signal relocation required.	N/A	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags 20" or more in width	N/A
Springer® Classic - FLSTSC/FLSTSCI	1984 to Present	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Standard - FXST/FXSTI	1984 to 2005	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Standard - FXST/FXSTI	2006 to Present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		* With 200mm wide rear tire GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Springer - FXSTS/FXSTSI	1984 to 2005	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Springer - FXSTS/FXSTSI	2006 to Present	GB-HD-ST200-105	GB1-ADJ-105 + GB1-KHK-HD-ST200	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
----------------------------------	-----------------	-----------------	--------------------------------	---------------------------------	-------------------------------------	-----------------------	---	--

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
* With 200mm wide rear tire		GB-HD-STSE200-105	GB1-ADJ-105 + GB1-KHK-HD-STSE200	Standard setup on front 2 bolts	No turn signal relocation required. FOR USE ON: Softail® Springer Screamin' Eagle® - FXSTSSE2 (2007 to Present) ONLY!!!	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200BK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-ST200DBK-105	GB1-ADJ-105 + GB1-KHK-HD-ST200DBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

Softail® Sturgis® - FXB	1984 to Present	GB-HD-ST-105	GB1-ADJ-105 + GB1-KHK-HD-ST	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-ST-DB - for detachable backrests
		GB-HD-STBK-105	GB1-ADJ-105 + GB1-KHK-HD-STBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-STDBK-105	GB1-ADJ-105 + GB1-KHK-HD-STDBK	Standard setup on front 2 bolts	No turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-UK-106	GB1-ADJ-106 + GB1-KHK-HD-UK	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-UKH-106	GB1-ADJ-106 + GB1-KHK-HD-UKH	Standard setup on rear 2 bolts	Turn signal relocation required.	No backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	GB-BK-HD-ST - for standard backrest GB-BK-HD-DNA-DB - for detachable backrests
		GB-HD-UKHBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-UKHDBK-106	GB1-ADJ-106 + GB1-KHK-HD-UKHDBK	Standard setup on rear 2 bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with OEM or aftermarket molded plastic back saddlebags such as Harley Heritage saddlebags	N/A
Harley Big Twin (With 3/8 bolt setup)	All Years	GB-HD-BT-105	GB1-ADJ-105 + GB1-KHK-HD-BT	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest
		GB-HD-BTBK-105	GB1-ADJ-105 + GB1-KHK-HD-BTBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-BT-106	GB1-ADJ-106 + GB1-KHK-HD-BT	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest
		GB-HD-BTBK-106	GB1-ADJ-106 + GB1-KHK-HD-BTBK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Harley Big Twin (With 5/16 bolt setup)	All Years	GB-HD-BT5-105	GB1-ADJ-105 + GB1-KHK-HD-BT5	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-ST - for standard backrest
		GB-HD-BT5BK-105	GB1-ADJ-105 + GB1-KHK-HD-BT5BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-BT5-106	GB1-ADJ-106 + GB1-KHK-HD-BT5	Standard setup on front 2 bolts	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-ST - for standard backrest
		GB-HD-BT5BK-106	GB1-ADJ-106 + GB1-KHK-HD-BT5BK	Standard setup on front 2 bolts	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Sportster®	1985 to 1993	GB-HD-SPT85-105	GB1-ADJ-105 + GB1-KHK-HD-SPT85	Standard setup on rear bolts	Turn signal relocation required. Old fine tread holes may need to be redrilled with standard 5/16 bit.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-SPT - for standard backrest
		GB-HD-SPT85-106	GB1-ADJ-106 + GB1-KHK-HD-SPT85	Standard setup on rear bolts	Turn signal relocation required. Old fine tread holes may need to be redrilled with standard 5/16 bit.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-SPT - for standard backrest
Sportster® Roadster® - XL / XLT / XLS / XLH / XR / FXB / XLX	1994 to 2003	GB-HD-SPT-105	GB1-ADJ-105 + GB1-KHK-HD-SPT	Standard setup on front and rear bolts	Turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-SPT - for standard backrest
		GB-HD-SPTBK-105	GB1-ADJ-105 + GB1-KHK-HD-SPTBK	Standard setup on front and rear bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-SPTDBK-105	GB1-ADJ-105 + GB1-KHK-HD-SPTDBK	Standard setup on front and rear bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-SPT-106	GB1-ADJ-106 + GB1-KHK-HD-SPT	Standard setup on front and rear bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-SPT - for standard backrest
		GB-HD-SPTBK-106	GB1-ADJ-106 + GB1-KHK-HD-SPTBK	Standard setup on front and rear bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-SPTDBK-106	GB1-ADJ-106 + GB1-KHK-HD-SPTDBK	Standard setup on front and rear bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
Sportster® Roadster® - XL / XLT / XLS / XLH / XR / FXB / XLX	2004 to Present	GB-HD-SPT04-105	GB1-ADJ-105 + GB1-KHK-HD-SPT04	Standard setup on front and rear bolts	Turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-HD-SPT - for standard backrest GB-BK-HD-SPT4-DB for detachable backrest
		GB-HD-SPT04BK-105	GB1-ADJ-105 + GB1-KHK-HD-SPT04BK	Standard setup on front and rear bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-SPT04DBK-105	GB1-ADJ-105 + GB1-KHK-HD-SPT04DBK	Standard setup on front and rear bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-HD-SPT04-106	GB1-ADJ-106 + GB1-KHK-HD-SPT04	Standard setup on front and rear bolts	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-HD-SPT - for standard backrest GB-BK-HD-SPT4-DB for detachable backrest
		GB-HD-SPT04BK-106	GB1-ADJ-106 + GB1-KHK-HD-SPT04BK	Standard setup on front and rear bolts	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-HD-SPT04DBK-106	GB1-ADJ-106 + GB1-KHK-HD-SPT04DBK	Standard setup on front and rear bolts	Turn signal relocation required.	Harley Davidson detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
Dyna Glide® - FXDB / FXRDG	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Glide® - FXDB / FXRDG	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Glide® - FXDB / FXRDG	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna - FXDS / FXDP / FXR2 / FXR3 / FXR4 / FXRD	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna - FXDS / FXDP / FXR2 / FXR3 / FXR4 / FXRD	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna - FXDS / FXDP / FXR2 / FXR3 / FXR4 / FXRD	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Low Rider® - FXDL/FXDLI	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Low Rider® - FXDL/FXDLI	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Low Rider® - FXDL/FXDLI	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Sport Glide® - FXRT	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Sport Glide® - FXRT	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Sport Glide® - FXRT	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Super Glide® - FXD / FXDG / FXDI / FXDC / FXDCI / FXDS / FXDX / FXDXI / FXDXT / FXE / FXR / FXEF	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Super Glide® - FXD / FXDG / FXDI / FXDC / FXDCI / FXDS / FXDX / FXDXI / FXDXT / FXE / FXR / FXEF	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Super Glide® - FXD / FXDG / FXDI / FXDC / FXDCI / FXDS / FXDX / FXDXI / FXDXT / FXE / FXR / FXEF	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Low Glide	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Low Glide	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Low Glide	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Screamin' Eagle® Switch Blade - FXDWG2 / FXDWG3	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Screamin' Eagle® Switch Blade - FXDWG2 / FXDWG3	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Screamin' Eagle® Switch Blade - FXDWG2 / FXDWG3	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
Dyna Wide Glide® - FXWG	1996 to 2003	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA-DB - for detachable backrest 1996-2003
		GB-HD-DNADBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNADBK	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Wide Glide® - FXWG	2004 to 2005	GB-HD-DNA-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA4-DB for detachable backrest 2004-UP
		GB-HD-DNA4DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Wide Glide® - FXWG	2006 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA06DBK	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Fat Bob® - FXDF	2008 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	No turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Dyna Street Bob® - FXDB	2008 to Present	GB-HD-DNA06-106	GB1-ADJ-106 + GB1-KHK-HD-DNA	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-HD-DNA06-DB for detachable backrest 2006-UP
		GB-HD-DNA06DBK-106	GB1-ADJ-106 + GB1-KHK-HD-DNA4DBK	Standard setup on front bolt and marker light bolt	Turn signal relocation required.	Harley Davidson detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A

HONDA

Shadow VT600 VLX	1999 to Present	GB-H-VLX-105	GB1-ADJ-105 + GB1-KHK-H-VLX	Standard 2 bolt setup	Turn signal relocation may be required	N/A	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VLX-106	GB1-ADJ-106 + GB1-KHK-H-VLX	Standard 2 bolt setup	Turn signal relocation may be required	N/A	For use with large saddlebags 20" or more in width	N/A
Shadow VT750 Spirit C2	2007 to Present	GB-H-VT7C4B-105	GB1-ADJ-105 + GB1-KHK-H-VT7C4B	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VT7C4B - for standard backrests front bolt mounting
		GB-H-VT7C4B-106	GB1-ADJ-106 + GB1-KHK-H-VT7C4B	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VT7C4B - for standard backrests front bolt mounting
		GB-H-VT7C4BBK-105	GB1-ADJ-105 + GB1-KHK-H-VT7C4BBK	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VT7C4BBK-106	GB1-ADJ-106 + GB1-KHK-H-VT7C4BBK	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Shadow VT750 Spirit DC	2000 to Present	GB-H-BW7-105	GB1-ADJ-105 + GB1-KHK-H-BW7	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-BW7 - for standard backrests rear bolt mounting
		GB-H-BW7-106	GB1-ADJ-106 + GB1-KHK-H-BW7	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-BW7 - for standard backrests rear bolt mounting
		GB-H-BW7BK-105	GB1-ADJ-105 + GB1-KHK-H-BW7BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-BW7BK-106	GB1-ADJ-106 + GB1-KHK-H-BW7BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-H-BW7PBK-105	GB1-ADJ-105 + GB1-KHK-H-BW7PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-BW7PBK-106	GB1-ADJ-106 + GB1-KHK-H-BW7PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
Shadow VT750 AERO	2004 to Present	GB-H-VT7C4-105	GB1-ADJ-105 + GB1-KHK-H-VT7C4	Standard 2 rear bolt setup	Turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VT7C4 - for standard backrests rear bolt mounting
		GB-H-VT7C4-106	GB1-ADJ-106 + GB1-KHK-H-VT7C4	Standard 2 rear bolt setup	Turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VT7C4 - for standard backrests rear bolt mounting
		GB-H-VT7C4B-105	GB1-ADJ-105 + GB1-KHK-H-VT7C4B	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VT7C4B - for standard backrests rear bolt mounting
		GB-H-VT7C4B-106	GB1-ADJ-106 + GB1-KHK-H-VT7C4B	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VT7C4B - for standard backrests front bolt mounting
		GB-H-VT7C4BK-105	GB1-ADJ-105 + GB1-KHK-H-VT7C4BK	Standard 2 rear bolt setup	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VT7C4BK-106	GB1-ADJ-106 + GB1-KHK-H-VT7C4BK	Standard 2 rear bolt setup	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VT7C4PBK-105	GB1-ADJ-105 + GB1-KHK-H-VT7C4PBK	Standard 2 rear bolt setup	Turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VT7C4PBK-106	GB1-ADJ-106 + GB1-KHK-H-VT7C4PBK	Standard 2 rear bolt setup	Turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VT7C4BBK-105	GB1-ADJ-105 + GB1-KHK-H-VT7C4BBK	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VT7C4BBK-106	GB1-ADJ-106 + GB1-KHK-H-VT7C4BBK	Standard 2 front bolt setup	No turn signal relocation required. OEM seat interferes with installation, aftermarket low profile seat required	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Shadow VT750 ACE	1997 to 2003	GB-H-VT7-105	GB1-ADJ-105 + GB1-KHK-H-VT7	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VT7 - for standard backrests rear bolt mounting
		GB-H-VT7-106	GB1-ADJ-106 + GB1-KHK-H-VT7	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VT7 - for standard backrests rear bolt mounting
		GB-H-VT7BK-105	GB1-ADJ-105 + GB1-KHK-H-VT7BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VT7BK-106	GB1-ADJ-106 + GB1-KHK-H-VT7BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VT7PBK-105	GB1-ADJ-105 + GB1-KHK-H-VT7PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VT7PBK-106	GB1-ADJ-106 + GB1-KHK-H-VT7PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
Magna VF750	1993 to 2003	GB-H-VF7-105	GB1-ADJ-105 + GB1-KHK-H-VF7	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VF7 - for standard backrests rear bolt mounting
		GB-H-VF7-106	GB1-ADJ-106 + GB1-KHK-H-VF7	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VF7 - for standard backrests rear bolt mounting
		GB-H-VF7BK-105	GB1-ADJ-105 + GB1-KHK-H-VF7BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VF7BK-106	GB1-ADJ-106 + GB1-KHK-H-VF7BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
Shadow VT1100 AERO	1995 to Present	GB-ADJ-105	GB1-ADJ-105 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	N/A	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-ADJ-106	GB1-ADJ-106 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	N/A	For use with large saddlebags 20" or more in width	N/A
Shadow VT1100 ACE	1995 to Present	GB-ADJ-105	GB1-ADJ-105 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	N/A	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-ADJ-106	GB1-ADJ-106 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	N/A	For use with large saddlebags 20" or more in width	N/A
Shadow VT1100 Sabre	1995 to Present	GB-ADJ-106	GB1-ADJ-106 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	Can be used with Paladin Detachable Backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-ADJ-105	GB1-ADJ-105 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	Can be used with Paladin Detachable Backrest	For use with large saddlebags 20" or more in width	N/A
Shadow VT1100 Spirit	1995 to Present	GB-ADJ-106	GB1-ADJ-106 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	Can be used with Paladin Detachable Backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-ADJ-105	GB1-ADJ-105 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	Can be used with Paladin Detachable Backrest	For use with large saddlebags 20" or more in width	N/A
Valkyrie	1997 to 2006	GB-H-F6-105	GB1-ADJ-105 + GB1-KHK-H-F6	Standard 2 bolt setup	No turn signal relocation required.	N/A	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-F6-106	GB1-ADJ-106 + GB1-KHK-H-F6	Standard 2 bolt setup	No turn signal relocation required.	N/A	For use with large saddlebags 20" or more in width	N/A
		GB-H-F6PBK-105	GB1-ADJ-105 + GB1-KHK-H-F6PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-F6PBK-106	GB1-ADJ-106 + GB1-KHK-H-F6PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
VTX 1300 C / F	2002 to Present	GB-H-VTXC-105	GB1-ADJ-105 + GB1-KHK-H-VTXC	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VTXC - for standard backrests rear bolt mounting GB-BK-H-VTXC-DL - for Hondaline Deluxe backrests
		GB-H-VTXC-106	GB1-ADJ-106 + GB1-KHK-H-VTXC	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VTXC - for standard backrests rear bolt mounting GB-BK-H-VTXC-DL - for Hondaline Deluxe backrests
		GB-H-VTXCBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXCDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrest	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXCPBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCPBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-H-VTXCSBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCSBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXCTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional backrest installed	For use with large saddlebags 20" or more in width	N/A

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
VTX 1800 C / F	2002 to Present	GB-H-VTXC-105	GB1-ADJ-105 + GB1-KHK-H-VTXC	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VTXC - for standard backrests rear bolt mounting GB-BK-H-VTXC-DL - for Hondaline Deluxe backrests
		GB-H-VTXC-106	GB1-ADJ-106 + GB1-KHK-H-VTXC	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VTXC - for standard backrests rear bolt mounting GB-BK-H-VTXC-DL - for Hondaline Deluxe backrests
		GB-H-VTXCBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXCDBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCDBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCDBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCDBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrest	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXCPBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCPBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXCSBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCSBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXCTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXCTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXCTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXCTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional backrest installed	For use with large saddlebags 20" or more in width	N/A

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
VTX 1300 R, S	2002 to Present	GB-H-VTXR-105	GB1-ADJ-105 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VTXR - for standard backrests rear bolt mounting
		GB-H-VTXR-106	GB1-ADJ-106 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VTXR-BR - for standard backrests rear bolt mounting
		GB-H-VTXRBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on Front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on Front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-H-VTXRFDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRFDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRFDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRFDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on Front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on Front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRFTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRFTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRSBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRSBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRNBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRNBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo-Retro Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRNBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRNBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo-Retro Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRPBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRPBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A

VTX 1800 R, S	2002 to Present	GB-H-VTXR-105	GB1-ADJ-105 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VTXR - for standard backrests rear bolt mounting
		GB-H-VTXR-106	GB1-ADJ-106 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VTXR-BR - for standard backrests rear bolt mounting
		GB-H-VTXRBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on Front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on rear two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRFDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRFDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRFDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRFDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on rear two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on rear two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRFTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-H-VTXRFTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRSBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRSBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRSBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Sport Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRNBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRNBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo-Retro Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRNBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRNBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo-Retro Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRPBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRPBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRPBK	Standard 2 rear bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	For use with large saddlebags 20" or more in width	N/A

VTX 1300 N	2002 to Present	GB-H-VTXR-105	GB1-ADJ-105 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VTXR - for standard backrests rear bolt mounting
		GB-H-VTXR-106	GB1-ADJ-106 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VTXR-BR - for standard backrests rear bolt mounting
		GB-H-VTXRNBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRNBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRNBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRNBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on Front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on Front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRFTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRFTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on Front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRFTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRFTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on Front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRFTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRFTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXNDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXNDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo Deluxe Backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXNDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXNDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo Deluxe Backrest	For use with large saddlebags 20" or more in width	N/A

VTX 1800 N	2002 to Present	GB-H-VTXR-105	GB1-ADJ-105 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-H-VTXR - for standard backrests rear bolt mounting
		GB-H-VTXR-106	GB1-ADJ-106 + GB1-KHK-H-VTXR	Standard 2 rear bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-H-VTXR-BR - for standard backrests rear bolt mounting

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-H-VTXRBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRBK	Standard 2 rear bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed on Rear 2 bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on Front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on Front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRDLBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Deluxe Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on Front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRTBK	Standard 2 rear bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on Front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXRFTBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXRFTBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXRFTBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Traditional Backrests installed on front two bolts ONLY	For use with large saddlebags 20" or more in width	N/A
		GB-H-VTXNDLBK-105	GB1-ADJ-105 + GB1-KHK-H-VTXNDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo Deluxe Backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-H-VTXNDLBK-106	GB1-ADJ-106 + GB1-KHK-H-VTXNDLBK	Standard 2 front bolt setup	No turn signal relocation required.	Hondaline Neo Deluxe Backrest	For use with large saddlebags 20" or more in width	N/A

YAMAHA

V Star 650 Custom	1997 to Present	GB-Y-VS-106	GB1-ADJ-106 + GB1-KHK-Y-VS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-VS for standard backrest
		GB-Y-VSBK-106	GB1-ADJ-106 + GB1-KHK-Y-VSBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
V Star 650 Classic	1997 to Present	GB-Y-VS-106	GB1-ADJ-106 + GB1-KHK-Y-VS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-VS for standard backrest
		GB-Y-VSBK-106	GB1-ADJ-106 + GB1-KHK-Y-VSBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-VSPBK-106	GB1-ADJ-106 + GB1-KHK-Y-VSPBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
V Star 650 Silverado	1997 to Present	GB-Y-VS-106	GB1-ADJ-106 + GB1-KHK-Y-VS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-VS for standard backrest
		GB-Y-VSBK-106	GB1-ADJ-106 + GB1-KHK-Y-VSBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
V Star 1100 Custom	1997 to Present	GB-Y-VS1-106	GB1-ADJ-106 + GB1-KHK-Y-VS1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-VS1 for standard backrest
		GB-Y-VS1BK-106	GB1-ADJ-106 + GB1-KHK-Y-VS1BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-VS1PBK-106	GB1-ADJ-106 + GB1-KHK-Y-VS1PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
V Star 1100 Classic	1997 to Present	GB-Y-VS1CL-106	GB1-ADJ-106 + GB1-KHK-Y-VS1CL	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-VSCL1 for standard backrest
		GB-Y-VS1CLBK-106	GB1-ADJ-106 + GB1-KHK-Y-VS1CLBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-VS1CLPBK-106	GB1-ADJ-106 + GB1-KHK-Y-VS1CLPBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
V Star 1100 Silverado	1997 to Present	GB-Y-VS1CL-106	GB1-ADJ-106 + GB1-KHK-Y-VS1CL	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-VSCL1 for standard backrest
		GB-Y-VS1CLBK-106	GB1-ADJ-106 + GB1-KHK-Y-VS1CLBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
V Star 1300	2007 to Present	GB-Y-VS13-106	GB1-ADJ-106 + GB1-KHK-Y-VS13	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-VS13 for standard backrest
		GB-Y-VS13BK-106	GB1-ADJ-106 + GB1-KHK-Y-VS13BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-VS13PBK-106	GB1-ADJ-106 + GB1-KHK-Y-VS13PBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-VS13OBK-106	GB1-ADJ-106 + GB1-KHK-Y-VS13OBK	Standard 2 bolt setup	No turn signal relocation required.	Yamaha OEM backrest installed	All saddlebags 12" or larger at mounting point	N/A
Road Star	1999 to Present	GB-Y-RS-106	GB1-ADJ-106 + GB1-KHK-Y-RS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-RS for standard backrest
		GB-Y-RSBK-106	GB1-ADJ-106 + GB1-KHK-Y-RSBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-RSDBK-106	GB1-ADJ-106 + GB1-KHK-Y-RSDBK	Standard 2 bolt setup	No turn signal relocation required.	Yamaha OEM detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-RSPBK-106	GB1-ADJ-106 + GB1-KHK-Y-RSPBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin Detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
Royal Star	1999 to Present	GB-Y-RS-106	GB1-ADJ-106 + GB1-KHK-Y-RS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-RS for standard backrest
		GB-Y-RSDBK-106	GB1-ADJ-106 + GB1-KHK-Y-RSDBK	Standard 2 bolt setup	No turn signal relocation required.	Yamaha OEM detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-RSBK-106	GB1-ADJ-106 + GB1-KHK-Y-RSBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
Roadliner	2006 to Present	GB-Y-RL-106	GB1-ADJ-106 + GB1-KHK-Y-RL	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-RL for standard backrest
		GB-Y-RLBK-106	GB1-ADJ-106 + GB1-KHK-Y-RLBK	Standard 2 bolt setup	No turn signal relocation required.	Aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-RLOBK-106	GB1-ADJ-106 + GB1-KHK-Y-RLOBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM factory backrest installed	All saddlebags 12" or larger at mounting point	N/A
Stratoliner	2006 to Present	GB-Y-RL-106	GB1-ADJ-106 + GB1-KHK-Y-RL	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-Y-RL for standard backrest
		GB-Y-RLBK-106	GB1-ADJ-106 + GB1-KHK-Y-RLBK	Standard 2 bolt setup	No turn signal relocation required.	Aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-Y-RLOBK-106	GB1-ADJ-106 + GB1-KHK-Y-RLOBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM factory backrest installed	All saddlebags 12" or larger at mounting point	N/A
Warrior	2002 to Present	GB-Y-WAR-105	GB1-ADJ-105 + GB1-KHK-Y-WAR	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-Y-WAR for standard backrest
		GB-Y-WAR-106	GB1-ADJ-106 + GB1-KHK-Y-WAR	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-Y-WAR for standard backrest
		GB-Y-WARBK-105	GB1-ADJ-105 + GB1-KHK-Y-WARBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-Y-WARBK-106	GB1-ADJ-106 + GB1-KHK-Y-WARBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Raider	2008 to Present	GB-Y-RD-106	GB1-ADJ-106 + GB1-KHK-Y-RD	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-Y-RD for standard backrest
		GB-Y-RDBK-106	GB1-ADJ-106 + GB1-KHK-Y-RDBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

SUZUKI

GZ 250	1999 to Present	GB-S-GZ250-105	GB1-ADJ-105 + GB1-KHK-S-GZ250	Standard 2 bolt setup	Turn signal relocation may be required	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-S-GZ250-106	GB1-ADJ-106 + GB1-KHK-S-GZ250	Standard 2 bolt setup	Turn signal relocation may be required	No backrest installed	For use with large saddlebags 20" or more in width	N/A
Volusia 800	2001 to Present	GB-S-VL8-106	GB1-ADJ-106 + GB1-KHK-S-VL8	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-S-VL8 for standard backrests
		GB-S-VL8BK-106	GB1-ADJ-106 + GB1-KHK-S-VL8BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
Boulevard C50	2001 to Present	GB-S-VL8-106	GB1-ADJ-106 + GB1-KHK-S-VL8	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed		GB-BK-S-VL8 for standard backrests
		GB-S-VL8BK-106	GB1-ADJ-106 + GB1-KHK-S-VL8BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
Boulevard M50	2001 to Present	GB-S-VL8-106	GB1-ADJ-106 + GB1-KHK-S-VL8	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed		GB-BK-S-VL8 for standard backrests
		GB-S-VL8BK-106	GB1-ADJ-106 + GB1-KHK-S-VL8BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
Marauder 1600	2002 to Present	GB-K-MS1-105	GB1-ADJ-105 + GB1-KHK-K-MS1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-K-MS1 - for standard backrests
		GB-K-MS1-106	GB1-ADJ-106 + GB1-KHK-K-MS1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-K-MS1 - for standard backrests
		GB-K-MS1ABK-105	GB1-ADJ-105 + GB1-KHK-K-MS1ABK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1ABK-106	GB1-ADJ-106 + GB1-KHK-K-MS1ABK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-K-MS1BK-105	GB1-ADJ-105 + GB1-KHK-K-MS1BK	Standard 2 bolt setup	No turn signal relocation required.	OEM factory backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1BK-106	GB1-ADJ-106 + GB1-KHK-K-MS1BK	Standard 2 bolt setup	No turn signal relocation required.	OEM factory backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-K-MS1FR-105	GB1-ADJ-105 + GB1-KHK-K-MS1FR	Standard 2 bolt setup	No turn signal relocation required.	OEM factory billet fender rails installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1FR-106	GB1-ADJ-106 + GB1-KHK-K-MS1FR	Standard 2 bolt setup	No turn signal relocation required.	OEM factory billet fender rails installed	For use with large saddlebags 20" or more in width	N/A
Boulevard M95	2002 to Present	GB-K-MS1-105	GB1-ADJ-105 + GB1-KHK-K-MS1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-K-MS1 - for standard backrests

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-K-MS1-106	GB1-ADJ-106 + GB1-KHK-K-MS1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-K-MS1 - for standard backrests
		GB-K-MS1ABK-105	GB1-ADJ-105 + GB1-KHK-K-MS1ABK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1ABK-106	GB1-ADJ-106 + GB1-KHK-K-MS1ABK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-K-MS1BK-105	GB1-ADJ-105 + GB1-KHK-K-MS1BK	Standard 2 bolt setup	No turn signal relocation required.	OEM factory backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1BK-106	GB1-ADJ-106 + GB1-KHK-K-MS1BK	Standard 2 bolt setup	No turn signal relocation required.	OEM factory backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-K-MS1FR-105	GB1-ADJ-105 + GB1-KHK-K-MS1FR	Standard 2 bolt setup	No turn signal relocation required.	OEM factory billet fender rails installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1FR-106	GB1-ADJ-106 + GB1-KHK-K-MS1FR	Standard 2 bolt setup	No turn signal relocation required.	OEM factory billet fender rails installed	For use with large saddlebags 20" or more in width	N/A
Boulevard M109R	2006 to Present	GB-S-M109-105	GB1-ADJ-105 + GB1-KHK-S-M109	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-S-M109 - for standard backrests
		GB-S-M109-106	GB1-ADJ-106 + GB1-KHK-S-M109	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-S-M109 - for standard backrests
		GB-S-M109BK-105	GB1-ADJ-105 + GB1-KHK-S-M109BK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-S-M109BK-106	GB1-ADJ-106 + GB1-KHK-S-M109BK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-S-M109OBK-105	GB1-ADJ-105 + GB1-KHK-S-M109OBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-S-M109OBK-106	GB1-ADJ-106 + GB1-KHK-S-M109OBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM backrest installed	For use with large saddlebags 20" or more in width	N/A
Boulevard M109 S / M109 Limited	2006 to Present	GB-S-M109-105	GB1-ADJ-105 + GB1-KHK-S-M109	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-S-M109 - for standard backrests
		GB-S-M109-106	GB1-ADJ-106 + GB1-KHK-S-M109	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-S-M109 - for standard backrests
		GB-S-M109BK-105	GB1-ADJ-105 + GB1-KHK-S-M109BK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-S-M109BK-106	GB1-ADJ-106 + GB1-KHK-S-M109BK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-S-M109OBK-105	GB1-ADJ-105 + GB1-KHK-S-M109OBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-S-M109OBK-106	GB1-ADJ-106 + GB1-KHK-S-M109OBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM backrest installed	For use with large saddlebags 20" or more in width	N/A
Boulevard C109R / C109RT	2008 to Present	GB-S-C109-106	GB1-ADJ-106 + GB1-KHK-S-C109	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-S-C109 - for standard backrests
		GB-S-C109BK-106	GB1-ADJ-106 + GB1-KHK-S-C109BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
Intruder VL1500	1998 to Present	GB-S-LC1-107	GB1-ADJ-107 + GB1-KHK-S-LC1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-S-LC1 - for standard backrests
		GB-S-LC1BK-107	GB1-ADJ-107 + GB1-KHK-S-LC1BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
Boulevard C90	2003 to Present	GB-S-LC1-107	GB1-ADJ-107 + GB1-KHK-S-LC1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-S-LC1 - for standard backrests
		GB-S-LC1BK-107	GB1-ADJ-107 + GB1-KHK-S-LC1BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

KAWASAKI

Vulcan 500 LTD	1995 to Present	GB-K-VN5LTD-106	GB1-ADJ-106 + GB1-KHK-K-VN5LTD	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-K-VN5LTD - for standard backrest
		GB-K-VN5LTDBK-106	GB1-ADJ-106 + GB1-KHK-K-VN5LTDBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A

Vulcan 800 / 800 Classic	1995 to Present	GB-K-VN8-105	GB1-ADJ-105 + GB1-KHK-K-VN8	Standard 2 bolt setup	Turn signal relocation may be required	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-K-VN8 - for standard backrest
		GB-K-VN8-106	GB1-ADJ-106 + GB1-KHK-K-VN8	Standard 2 bolt setup	Turn signal relocation may be required	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-K-VN8 - for standard backrest
		GB-K-VN8BK-105	GB1-ADJ-105 + GB1-KHK-K-VN8BK	Standard 2 bolt setup	Turn signal relocation may be required	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-VN8BK-106	GB1-ADJ-106 + GB1-KHK-K-VN8BK	Standard 2 bolt setup	Turn signal relocation may be required	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

Vulcan 900 Custom / Classic	2005 to Present	GB-K-VN9C-106	GB1-ADJ-106 + GB1-KHK-K-VN9C	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-K-VN9C - for standard backrest
		GB-K-VN9CBK-106	GB1-ADJ-106 + GB1-KHK-K-VN9CBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
		GB-K-VN9CPBK-106	GB1-ADJ-106 + GB1-KHK-K-VN9CPBK	Standard 2 bolt setup	No turn signal relocation required.	Paladin detachable backrest installed	All saddlebags 12" or larger at mounting point	N/A

Vulcan 1500	1997 to Present	GB-ADJ-105	GB1-ADJ-105 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	N/A		N/A
		GB-ADJ-106	GB1-ADJ-106 + GB1-KHK-U-ADJ	Standard 2 bolt setup	Turn signal relocation may be required	N/A		N/A

Vulcan 1500 Classic	1996 to Present	GB-K-VN15CL-105	GB1-ADJ-105 + GB1-KHK-K-VN15CL	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-K-VN15CL - for standard backrest
		GB-K-VN15CL-106	GB1-ADJ-106 + GB1-KHK-K-VN15CL	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-K-VN15CL - for standard backrest
		GB-K-VN15CLBK-105	GB1-ADJ-105 + GB1-KHK-K-VN15CLBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-VN15CLBK-106	GB1-ADJ-106 + GB1-KHK-K-VN15CLBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

Mean Streak 1500 / 1600	2002 to Present	GB-K-MS1-105	GB1-ADJ-105 + GB1-KHK-K-MS1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-K-MS1 - for standard backrests
		GB-K-MS1-106	GB1-ADJ-106 + GB1-KHK-K-MS1	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-K-MS1 - for standard backrests
		GB-K-MS1ABK-105	GB1-ADJ-105 + GB1-KHK-K-MS1ABK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1ABK-106	GB1-ADJ-106 + GB1-KHK-K-MS1ABK	Standard 2 bolt setup	No turn signal relocation required.	Standard aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-K-MS1BK-105	GB1-ADJ-105 + GB1-KHK-K-MS1BK	Standard 2 bolt setup	No turn signal relocation required.	OEM factory backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1BK-106	GB1-ADJ-106 + GB1-KHK-K-MS1BK	Standard 2 bolt setup	No turn signal relocation required.	OEM factory backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-K-MS1FR-105	GB1-ADJ-105 + GB1-KHK-K-MS1FR	Standard 2 bolt setup	No turn signal relocation required.	OEM factory billet fender rails installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-MS1FR-106	GB1-ADJ-106 + GB1-KHK-K-MS1FR	Standard 2 bolt setup	No turn signal relocation required.	OEM factory billet fender rails installed	For use with large saddlebags 20" or more in width	N/A

Vulcan 1600	1996 to Present	GB-ADJ-105 GB-ADJ-106	GB1-ADJ-105 + GB1-KHK-U-ADJ GB1-ADJ-106 + GB1-KHK-U-ADJ	Standard 2 bolt setup Standard 2 bolt setup	Turn signal relocation may be required Turn signal relocation may be required	N/A N/A		N/A N/A
-------------	-----------------	--------------------------	--	--	--	------------	--	------------

Vulcan 1600 Classic	1996 to Present	GB-K-VN16-105	GB1-ADJ-105 + GB1-KHK-K-VN16	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-K-VN16 - for standard backrest
		GB-K-VN16-106	GB1-ADJ-106 + GB1-KHK-K-VN16	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-K-VN16 - for standard backrest
		GB-K-VN16BK-105	GB1-ADJ-105 + GB1-KHK-K-VN16BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-K-VN16BK-106	GB1-ADJ-106 + GB1-KHK-K-VN16BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

Vulcan 1700 (All Models)	2009 to Present	GB-K-VN17-106	GB1-ADJ-106 + GB1-KHK-K-VN17	Standard 2 bolt setup	Turn signal relocation may be required	No backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-K-VN17BK-106	GB1-ADJ-106 + GB1-KHK-K-VN17BK	Standard 2 bolt setup	Turn signal relocation may be required	Standard OEM or aftermarket backrest	For use with small, medium or	N/A

Vulcan 2000	2004 to Present	GB-K-VN20-106	GB1-ADJ-106 + GB1-KHK-K-VN20	Standard 2 bolt setup	Turn signal relocation may be required	No backrest installed	For use with large saddlebags 20" or more in width	N/A
		GB-K-VN20BK-106	GB1-ADJ-106 + GB1-KHK-K-VN20BK	Standard 2 bolt setup	Turn signal relocation may be required	Standard OEM or aftermarket backrest	For use with small, medium or	N/A

VICTORY POLARIS

Classic Cruiser V92C	2000 - Present	GB-P-VP-105	GB1-ADJ-105 + GB1-KHK-P-VP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VP - for standard backrests
		GB-P-VP-106	GB1-ADJ-106 + GB1-KHK-P-VP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VP - for standard backrests
		GB-P-VPBK-105	GB1-ADJ-105 + GB1-KHK-P-VPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VPBK-106	GB1-ADJ-106 + GB1-KHK-P-VPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

Touring Cruiser	2000 - Present	GB-P-VP-105	GB1-ADJ-105 + GB1-KHK-P-VP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VP - for standard backrests
		GB-P-VP-106	GB1-ADJ-106 + GB1-KHK-P-VP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VP - for standard backrests
		GB-P-VPBK-105	GB1-ADJ-105 + GB1-KHK-P-VPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VPBK-106	GB1-ADJ-106 + GB1-KHK-P-VPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
Vegas	2003 - Present	GB-P-VV-105	GB1-ADJ-108 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VV-106	GB1-ADJ-109 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat.	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
		GB-P-VVLR-105	GB1-ADJ-108 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVLR-106	GB1-ADJ-109 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with large saddlebags 20" or more in width	N/A
Vegas 8-ball	2005 - Present	GB-P-VV-105	GB1-ADJ-108 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VV-106	GB1-ADJ-109 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
		GB-P-VVLR-105	GB1-ADJ-108 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVLR-106	GB1-ADJ-109 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with large saddlebags 20" or more in width	N/A
Vegas Low	2008 - Present	GB-P-VV-105	GB1-ADJ-108 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VV-106	GB1-ADJ-109 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
		GB-P-VVLR-105	GB1-ADJ-108 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVLR-106	GB1-ADJ-109 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
Vegas Jackpot	2006 - Present	GB-P-VVKP-105	GB1-ADJ-105 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKP-106	GB1-ADJ-106 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKPBK-105	GB1-ADJ-105 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVKPBK-106	GB1-ADJ-106 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
Hammer	2005 - Present	GB-P-VVKP-105	GB1-ADJ-105 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKP-106	GB1-ADJ-106 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKPBK-105	GB1-ADJ-105 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVKPBK-106	GB1-ADJ-106 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
Hammer S	2007 - Present	GB-P-VVKP-105	GB1-ADJ-105 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKP-106	GB1-ADJ-106 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKPBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVKPBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
Kingpin	2004 - Present	GB-P-VV-105	GB1-ADJ-108 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VV-106	GB1-ADJ-109 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
		GB-P-VVLR-105	GB1-ADJ-108 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-P-VVLR-106	GB1-ADJ-109 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with large saddlebags 20" or more in width	N/A
Kingpin Tour	2007 - Present	GB-P-VV-105	GB1-ADJ-108 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VV-106	GB1-ADJ-109 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
		GB-P-VVLR-105	GB1-ADJ-108 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVLR-106	GB1-ADJ-109 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with large saddlebags 20" or more in width	N/A
Kingpin 8-ball	2008 - Present	GB-P-VV-105	GB1-ADJ-108 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VV-106	GB1-ADJ-109 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
		GB-P-VVLR-105	GB1-ADJ-108 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVLR-106	GB1-ADJ-109 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with large saddlebags 20" or more in width	N/A
Kingpin Low	2008 - Present	GB-P-VV-105	GB1-ADJ-108 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VV-106	GB1-ADJ-109 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVBK-105	GB1-ADJ-108 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVBK-106	GB1-ADJ-109 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A
		GB-P-VVLR-105	GB1-ADJ-108 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-P-VVLR-106	GB1-ADJ-109 + GB1-KHK-P-VVKPLR	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM Luggage Rack is installed on the rear two bolts of the fender rails.	For use with large saddlebags 20" or more in width	N/A
Ness Signature Series Jackpot	2006 - Present	GB-P-VVKP-105	GB1-ADJ-105 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKP-106	GB1-ADJ-106 + GB1-KHK-P-VVKP	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-P-VVKP - for standard backrests
		GB-P-VVKPBK-105	GB1-ADJ-105 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-P-VVKPBK-106	GB1-ADJ-106 + GB1-KHK-P-VVKPBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed on fenderrails. Not applicable to backrest attached to the seat	For use with large saddlebags 20" or more in width	N/A

INDIAN

Indian Chief	1999 to 2005	GB-I-IIS-105	GB1-ADJ-105 + GB1-KHK-I-IIS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-I-IIS - for standard backrests
		GB-I-IIS-106	GB1-ADJ-106 + GB1-KHK-I-IIS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-I-IIS - for standard backrests
		GB-I-IISBK-105	GB1-ADJ-105 + GB1-KHK-I-IISBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-I-IISBK-106	GB1-ADJ-106 + GB1-KHK-I-IISBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

Indian Spirit	1999 to 2005	GB-I-IIS-105	GB1-ADJ-105 + GB1-KHK-I-IIS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-I-IIS - for standard backrests
		GB-I-IIS-106	GB1-ADJ-106 + GB1-KHK-I-IIS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-I-IIS - for standard backrests
		GB-I-IISBK-105	GB1-ADJ-105 + GB1-KHK-I-IISBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-I-IISBK-106	GB1-ADJ-106 + GB1-KHK-I-IISBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

Indian Scout	1999 to 2005	GB-I-IIS-105	GB1-ADJ-105 + GB1-KHK-I-IIS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-I-IIS - for standard backrests
		GB-I-IIS-106	GB1-ADJ-106 + GB1-KHK-I-IIS	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-I-IIS - for standard backrests
		GB-I-IISBK-105	GB1-ADJ-105 + GB1-KHK-I-IISBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-I-IISBK-106	GB1-ADJ-106 + GB1-KHK-I-IISBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

TRIUMPH

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
America	1999 to Present	GB-T-ASM-105	GB1-ADJ-105 + GB1-KHK-T-ASM	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-T-ASM - for standard backrests
		GB-T-ASM-106	GB1-ADJ-106 + GB1-KHK-T-ASM	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-T-ASM - for standard backrests
		GB-T-ASMBK-105	GB1-ADJ-105 + GB1-KHK-T-ASMBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-T-ASMBK-106	GB1-ADJ-106 + GB1-KHK-T-ASMBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Speedmaster	2001 to Present	GB-T-ASM-105	GB1-ADJ-105 + GB1-KHK-T-ASM	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-T-ASM - for standard backrests
		GB-T-ASM-106	GB1-ADJ-106 + GB1-KHK-T-ASM	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-T-ASM - for standard backrests
		GB-T-ASMBK-105	GB1-ADJ-105 + GB1-KHK-T-ASMBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-T-ASMBK-106	GB1-ADJ-106 + GB1-KHK-T-ASMBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Rocket 3	2001 to Present	GB-T-R3-106	GB1-ADJ-106 + GB1-KHK-T-R3	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-T-R3 - for standard backrests
		GB-T-R3BK-106	GB1-ADJ-106 + GB1-KHK-T-R3BK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A
Adventurer	1995 to 2003	GB-T-ADV-106	GB1-ADJ-106 + GB1-KHK-T-ADV	Standard 2 bolt setup	Turn signal relocation required.	No backrest installed	All saddlebags 12" or larger at mounting point	GB-BK-T-ADV - for standard backrests
		GB-T-ADV BK-106	GB1-ADJ-106 + GB1-KHK-T-ADV BK	Standard 2 bolt setup	Turn signal relocation required.	Standard OEM or aftermarket backrest installed	All saddlebags 12" or larger at mounting point	N/A

RIDLEY

X88	2003 - Present	GB-R-AG-105	GB1-ADJ-105 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-R-AG - for standard backrests
		GB-R-AG-106	GB1-ADJ-106 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-R-AG - for standard backrests
		GB-R-AGBK-105	GB1-ADJ-105 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-R-AGBK-106	GB1-ADJ-106 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Auto-Glide Classic	2003 - Present	GB-R-AG-105	GB1-ADJ-105 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-R-AG - for standard backrests
		GB-R-AG-106	GB1-ADJ-106 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-R-AG - for standard backrests
		GB-R-AGBK-105	GB1-ADJ-105 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-R-AGBK-106	GB1-ADJ-106 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
Auto-Glide Old School	2003 - Present	GB-R-AG-105	GB1-ADJ-105 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-R-AG - for standard backrests
		GB-R-AG-106	GB1-ADJ-106 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-R-AG - for standard backrests
		GB-R-AGBK-105	GB1-ADJ-105 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-R-AGBK-106	GB1-ADJ-106 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Auto-Glide Sport	2003 - Present	GB-R-AG-105	GB1-ADJ-105 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-R-AG - for standard backrests
		GB-R-AG-106	GB1-ADJ-106 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-R-AG - for standard backrests
		GB-R-AGBK-105	GB1-ADJ-105 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-R-AGBK-106	GB1-ADJ-106 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
Auto-Glide TT	2003 - Present	GB-R-AG-105	GB1-ADJ-105 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-R-AG - for standard backrests
		GB-R-AG-106	GB1-ADJ-106 + GB1-KHK-R-AG	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-R-AG - for standard backrests
		GB-R-AGBK-105	GB1-ADJ-105 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-R-AGBK-106	GB1-ADJ-106 + GB1-KHK-R-AGBK	Standard 2 bolt setup	No turn signal relocation required.	Standard OEM or aftermarket backrest installed	For use with large saddlebags 20" or more in width	N/A
MOTO GUZZI								
California EV 1100	1999 to 2005	GB-M-EV11-105	GB1-ADJ-105 + GB1-KHK-M-EV11	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with small, medium or slanted saddlebags 22" or less in width	GB-BK-I-IIS - for standard backrests
		GB-M-EV11-106	GB1-ADJ-106 + GB1-KHK-M-EV11	Standard 2 bolt setup	No turn signal relocation required.	No backrest installed	For use with large saddlebags 20" or more in width	GB-BK-I-IIS - for standard backrests
BOSS HOSS								
BHC-3 ZZ4 SS	2008 to Present	GB-BH-SS-105	GB1-ADJ-105 + GB1-KHK-BH-SS	Standard 2 bolt setup	No turn signal relocation required.	For use with or without the backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A
		GB-BH-SS-106	GB1-ADJ-106 + GB1-KHK-BH-SS	Standard 2 bolt setup	No turn signal relocation required.	For use with or without the backrest	For use with large saddlebags 20" or more in width	N/A
BHC-3 LS2	2008 to Present	GB-BH-SS-105	GB1-ADJ-105 + GB1-KHK-BH-SS	Standard 2 bolt setup	No turn signal relocation required.	For use with or without the backrest	For use with small, medium or slanted saddlebags 22" or less in width	N/A

**EDGE™ Brackets Quick Release Detachable Saddlebag System
FITMENT CHART**

MODEL	YEAR	BRACKET	COMPONENTS INCLUDED	CONFIGURATION NOTES	INSTALL NOTES	BACKREST USE	SADDLEBAG USE	BACKREST INTEGRATION IF BACKREST INSTALLED AFTER GHOST BRACKETS
		GB-BH-SS-106	GB1-ADJ-106 + GB1-KHK-BH-SS	Standard 2 bolt setup	No turn signal relocation required.	For use with or without the backrest	For use with large saddlebags 20" or more in width	N/A

****All information contained herein is for reference only and can change without notice at any time.**
© 2008 Property of CAO Distributing, Inc. All rights reserved.**